
PARTS LIST Model 5 Rimfire Bolt-Action Exploded View



1 2 3 4 5 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24	Magazine bottom plate Magazine bottom plate Magazine box Magazine bottom lock piece Follower Receiver Bolt body Barrel Bolt handle Extractor, left Extractor, right Trigger holder Trigger Safety Trigger screw Ejector Magazine carrier Magazine carrier Magazine holder Spring holder Cover Ejector securing pin Safety lever Plug	27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49	Abutment screw Regulating screw Extractor axle Trigger spring screw Magazine holder spring Screw Firing pin spring Magazine holder spring Stock Trigger guard Magazine holder button Screw Distance bushing Carrier Front sight base Screw Front sight Rear sight base Base screw Rear sight carrier Plate carrier Rear sight plate Rear sight spring
	Plug	49	Rear sight spring
25 26	Firing pin Magazine holder axle	50 51	Rear sight axle Plate screw